BLUEPORT

2x100W Portable PA System



USER MANUAL

soundsation

Dear customer,

first of ali thanks far purchasing **a SOUNDSATION®** product. Our mission is to satisfy all the possible needs of musical instrument and professional audio users offering a wide range of products using the latest technologies.

We hope you will be satisfied with this item and, ifyou want to collaborate, we are looking far **a feedback** from you about the operatian of the product and far passible improvements to introduce in the next future. Go to our website www.soundsationmusic.com and send an e-mail with your opinion, this will help us to build instruments ever closer to customer's real requirements.

One last thing: read this manual before using the instrument, an incorrect operation can cause damages to you and to the unit. Take care!

The SOUNDSATION Team

TABLE OF CONTENTS

UNBOXING.....4

ACCESSORIES.....4

GENERAL WARNINGS.....5

OVERVIEW.....6

FEATURES.....7

SETUP.....8

MIXER CONNECTION.....9

MIC/LINE INPUTS.....10

STEREO LINE INPUTS.....10

MASTER SECTION.....10

POWER SECTION.....10

FX SECTION.....11

BLUETOOTH SECTION.....11

REMOTE CONTROL.....11

WARRANTY & SERVICE 12

LEGAL INFORMATION & CONTACTS 13

UNBOXING

When you'll open the box you will find the following items:

- 2 passive speakers with integrated mixer
- 2 Connection cables
- 1 Power Cord
- 1 Remote Control
- User Manual

The packaging bag is not a toy! Keep out of reach of children!!!

Keep in a safe place the original packaging material for future use.

ACCESSORIES

SOUNDSATION can supply a wide range of quality accessories that you can use with the BLUEPORT Device like Cables, Microphones, Headphones.

All the products from our catalogue has been long tested with this device so we recommend to use Genuine SOUNDSATION Accessories and Spare Parts.

Ask your SOUNDSATION dealer for any accessories you could need to ensure best performance of the product.

GENERAL WARNINGS

To prevent possible damages read the following list of actions:

- Do not place the instrument in wet or dirty environments.

- Do not remove the protective coverings.

-Do not cover any of the instrument's ventilation holes.

- Air must circulate freely around the instrument.

- Do not set the instrument on a surface with excessive vibration.

- Do not expose the instrument to electro-magnetic interference.

- Do not expose the instrument to heat, cold, wet or dust.

- Do not leave the instrument in direct sunlight.

- Do not expose the instrument to electrostatic forces.

- Do not place items with flames, such as candles or lighters, on the instrument.

- Do not place the instrument on anything containing water or other fluids.

If any foreign objects enter the instrument, please contact your dealer or an authorized **SOUNDSATION** center.

The **serial number**, electrical features and international standards are printed on a label located in the back panel.

In case of problems remember to give the serial number to the responsible of the technical assistance.

OVERVIEW

The **BLUEPORT** system is designed to be a powerful resource for live and educational purpose. The friendly user interface is one of the best features of this product and this allow you to configure your sound device in a fast and easy way.

The integrated 8 Channel Mixer let you plug all the microphones or instrument you need for the entertainment thanks to the Combo inputs (XLR/Jack), the RCA or the mini-jack interface on Ch7/8 that allows you to plug a computer (Win or Mac), a smartphone or a portable MP3 player.

To reach the best performance **BLUEPORT** is equipped with a 24BIT DSP FX with up to 14 genuine effects to add to your MIC inputs choosing the amount for each Channel with the related knob integrated in every Channel Strip.

To let the the BLUEPORT be an advanced Multimedia Station SOUNDSATION introduced in this system the USB input to plug an USB Mass Storage as well as a BLUETOOTH device allowing you to give a signal in WIRELESS mode with an external source (Smartphone, Tablet, etc.)

The Remote Control let you control all the sources so you can change tracks, control the volume or the equalization as well as play or stop the track.

FEATURES

- 2 x 100 W Class D Amplifier
- 2 x Bass Reflex High Efficiency Enclosures
- Integrated 8 Channel Powered Mixer (4 Mono Mic/Line – 2 x Stereo Line)
- Monitor & Headphone Out
- IR Remote Control
- 24 BIT DSP FX Processor
- SSD/MMC/USB Inputs
- Integrated BLUETOOTH Module
- 15÷48 V Phantom Power
- Dual Band EQ (Bass- Treble)
- 35mm Mounting Hole
- 1 x 10” LF Speaker
- 1 x 1,34” HF Tweeter
- Maximum SPL Out 124dB
- Frequency Range: 50Hz to 20KHz
- AC Input 120-240 V – 50/60Hz - Fuse T2A

SETUP

When you'll open the boxes you will find the 2 Speakers. Each Speaker has got a removable back panel. In one Panel you find the Powered mixer, in the other one there is a pocket conteining the connecting cables, the power cord, the IR Remote Control and this manual.

PRESS AND SLIDE TO OPEN



The Speakers has got the traditional mounting hole on the Bottom. We reccomend to use SOUNDSATION SSPS-100BK or SSPS-100AL Speaker Stands.

SSPS-100AL

MIXER

TOP VIEW

SIDE VIEW



CONNECTION



MIC/Line In (MONO)

Peak LED indicator

Combo input (XLR-Jack)

Mic/Line switch

Use MIC position only for Microphones!!!

EQ section

Effect Amount

Channel Volume

Stereo Line In

Jack Inputs Line 5/6

RCA Inputs Line 5/6

Channel 5/6 Volume

Mini-Jack Input Line 7/8

Monitor Out

Jack Outputs Monitor Out

RCA Outputs Monitor Out

Monitor Out Volume

Mini-Jack Output Headphone

Master Section

General Volume off all Channels

Power Section

Power On LED indicator

Phantom Power Switch

Phantom Power LED indicator

FX Section



DIGITAL EFFECT LIST

0. WARM HALL	8. STEREO DELAY1
1. BRIGHT HALL	9. STEREO DELAY 2
2. WARM ROOM	A. REVERB+DELAY 1
3. BRIGHT ROOM	B. REVERB+DELAY 2
4. VOCAL 1	C. REVERB+DELAY 3
5. VOCAL 2	D. REV+DELAY 4
6. VOCAL 3	E. REV+CHORUS 1
7. PLATE	F. REV+CHORUS 2

Bluetooth Section



A.Play/Pause
Press this button to play the chosen song.Press it again to momentarily interrupt the playing.
Press a third time to continue the reading of the song.
B.Next/Vol+
Press this button once to go to the next song.
Press and hold this button to increase the volume of the Mp3 reader.
C.Previous/Vol-
Press this button once to come back to the previous song.
Press and hold this button to lower the volume of the Mp3 reader.
D.Repeat
Press this button once to play the current song repeatedly
E.MODE
Use this knob select the USB memory card or SD/MMC memory card or bluetooth mode.
BLUETOOTH PASSWORD: 0000
F.Stop
Press this button to end the song.

Remote Control



1. PLAY/PAUSE(see 4.A.)
2. FM CHANNEL -
3. FM CHANNEL +
4. VOLUME -
5. VOLUME +
6. FORWARD
7. BACK
8. EQ SELECT
9. FM, USB/SD

BATTERY -The remote control unit needs a Cr2025 button-cell battery to operate. In case of malfunction, always replace with the same type of battery. Dispose properly of the used battery for waste and recycling purposes.

Max Distance Operation : 3 Meters

WARRANTY & SERVICE

All SOUNDSATION products feature a limited two-year warranty. This two-year warranty is specific to the date of purchase as shown on your purchase receipt.

The following cases/components are not covered from the above warranty :

- Any accessories supplied with the product
- Improper use
- Fault due to wear and tear
- Any modification of the product effected by the user or a third party

SOUNDSATION shall satisfy the warranty obligations by remedying any material or manufacturing faults free of charge at SOUNDSATION's discretion either by repair or by exchanging individual parts or the entire appliance. Any defective parts removed from a product during the course of a warranty claim shall become the property of SOUNDSATION

While under warranty period, defective products may be returned to your local SOUNDSATION dealer together with original proof of purchase. To avoid any damages in transit, please use the original packaging if available. Alternatively you can send the product to SOUNDSATION SERVICE CENTER – Via Enzo Ferrari , 10 – 62017 Porto Recanati - Italy . In order to send a product to service center you need an RMA number. Shipping charges have to be covered by the owner of the product.

For further information please visit www.soundsationmusic.com

WARNING

PLEASE READ CAREFULLY – EU and EEA (Norway, Iceland and Liechtenstein) only



This symbol indicates that this product is not to be disposed of with your household waste, according to the WEEE Directive (2202/96/EC) and your national law.

This product should be handed over to a designated collection point, e.g., on an authorized one-for-one basis when you buy a new similar product or to an authorized collection site for recycling waste electrical and electronic equipment (WEEE) .

Improper handling of this type of waste could have a possible negative impact on the environment and human health due to potentially hazardous substances that are generally associated with EEE. At the same time , your cooperation in the correct disposal of this product will contribute to the effective usage of natural resources.

For more information about where you can drop off your waste equipment for recycling , please contact your local city office , waste authority , approved WEEE scheme or your household waste disposal service.

Contents and images shown on this manual can be changed without any notice. Please visit our website www.soundsationmusic.com to check latest version.

DESIGNED IN ITALY BY SOUNDSATION®

BLUEPORT USER MANUAL REV. 1.01

MADE IN CHINA

All the Trademarks are property of their respective owners

SOUNDSATION® is a registered trademark of

FRENEXPORT SPA – Via Enzo Ferrari, 10 - 62017 Porto Recanati – Italy

© SOUNDSATION 2013 – All rights reserved – All total or partial reproduction of this manual by any other company or person without express authorization of Soundsation is strictly forbidden.